## Assembling the HD3 stand

## Package includes:

- 4 panels
- 1 bottom panel
- 8 screws for the bottom
- 6 feet

- 2 screws for securing the display on top of the stand

- Umbraco key
- 8 wing nuts + bolt
- 4 Plastic screw rivet
- 2 Steel rods









Secure the panels at the bottom with 4 screws \applied internally





Place the bottom panel and secure with 8 screws

Screw in all 6 feet. 4 in the corners and 2 in the middle



Turn the stand upside down

Secure the panels at the top with 4 screws applied internally

Insert two bolts in the front and secure with bolts. Place the Dreamoc on top of the display.





## Locking the HD3 to the stand

It is very important to lock the HD3 display to the stand, and place a lot of weight at the bottom of the stand, in high traffic areas.

Remove the HD3 from the stand and turn it around, so the plate with the hole for the vesa mount is at the front.



Slide the HD3 down on top of the stand, so the steel rods will lock the back of the HD3 to the stand.

Remove both back plates and the center stage



Insert the 2 plastic screw rivets

inside the stand in the 2 holes

close to the front corners. Make

sure that the plastic screw rivets are going through both the holes in the stand close to the front corners and the holes in the front bottom of HD3, so the front of HD3 will be locked to the stand. Insert the steels rods into the plastic base of HD3 and push the steel as far as possible into the HD3 plastic base.



Place the center stage and back plates in the display again.

For support please visit www.realfiction.com/support/dreamoc-hd3.2-support



For further information and pricing please contact Realfiction Phone: +45 70 20 64 90 email: contact@realfiction.com Realfiction and Dreamoc are registered trademarks owned by Realfiction ApS. Other marks may be mentioned here in that belong to other companies. © 2019 Realfcition Aps. All rights reserved.