



# How to change the LED lamp in POP3 display

- 


1. Unlock top lid with POP3 key (the same key used for the glass lock)

- 

2. Lift up and take away the top lid

- 


3. Unplug the lamp cord from the screen

- 

4. Unscrew the 4 screws that holds the metal plate. Be sure to have one hand holding the metal plate to prevent this from falling down when being loose.




5. Take out the metal plate with the LED lamp and Lamp house and place on a table




6. Turn the metal plate and remove the 4 screws shown on the picture




7. You will then have the LED lamp house separated



8. Unscrew the 2 screws shown here to remove the lamp shade



9. Cut the plastic strip holding the cord to be able to take the cord through the hole



10. Unscrew the 2 screws shown on the picture. You can then remove the defective LED lamp and cord from the metal plate. Take the new LED lamp and the white heating pad. Place the white heating pad on the metal plate and after place the LED lamp on the white heating pad and secure with the 2 screws. Now you have to go back through the above steps to assemble the POP3 again.